

## **DISHWASHER PROCEDURES QGH**

### **FILLING THE DISHWASHER:**

Shut door and push power button **ON**.

### **DISHWASHING:**

Rinse/ soak all dishes, pots, and pans. Ensure all debris, and soap is thoroughly rinsed. Run dishes through machine, and allow to air dry before putting away.

For certain pots and pans that are too large for dish machine, or plastics items that could easily break please refrain from putting through the dish machine.

### **CLEANING – After each meal:**

1. Push power button OFF.
2. Open the door.
3. Drain machine by lifting drain lever up.
4. Ensure there are no items remaining in dishwasher (ex. Forks or knives)
5. Cool down the inside of dishwasher down by spraying cold water from hose.
6. Remove all strainer pans and strainer baskets. Empty contents into garburator. Thoroughly clean pans and baskets after each meal period.
7. Thoroughly wash out the inside of the machine with a hose/bucket of water. Remove any remaining debris with a cloth. Rinse again with hose/bucket of water. Do not allow food debris to accumulate on the bottom of the tank.
8. Return all strainer pans, strainer baskets to their original locations.
9. Leave the doors open while the machine is not in use to allow the interior to air and dry out.